How To Upgrade EVO XFinity

The latest softwares can include new features, improvements and also several fixes for various issues, therefore it is highly recommended to always keep your software up-to-date on your Set-Top Box. To do that, you can follow the following method:

Please follow the following method:

- Download the latest software from the internet.
- After the download, you should have a file called **update.zip**
- Copy the **update.zip** file to the root ("/") directory of a USB stick formatted to **FAT32**
- **Unplug** the power adapter from the Set Top Box's **DC IN** socket
- Connect the USB stick to the Set Top Box's USB port located on the front panel, behind the slapdoor
- Press and hold the **VOL-** button on the Set Top Box's front panel
- Plug in the power adapter while still holding the **VOL-** button
- When you see the Android Upgrade screen (see figure 1.), you can release the **VOL-** button
- After the upgrade finished, the Set Top Box will automatically restart with the new software

figure 1., Android upgrade screen